
9 1 2 3 4 5 6 6 CLYSSAROST

- **■** Front personal lights $(\rightarrow P. 424)$
- ightharpoonup Front interior light (ightharpoonupP. 424)
- Shift lever light (when the "POWER" switch is in ACCESSORY or ON mode)
- 4 Rear personal lights (\rightarrow P. 424)
- 5 Rear interior light
- 6 Door courtesy lights
- ▼ Scuff lights (if equipped)
- **8** Footwell lights
- 9 Outer foot lights


Interior lights



- Turns the lights on/off linked to door positions.
- Turns the lights on/off


Personal lights

► Front



Turns the light on/off

► Rear



Turns the light on/off

n Illuminated entry system

The lights automatically turn on/off according to "POWER" switch mode, the presence of the electronic key, whether the doors are locked/unlocked, and whether the doors are open/closed.

n To prevent 12-volt battery discharge

If the interior lights remain on when the door is not fully closed and the interior light switch (door position on/ off) is on, the lights will go off automatically after 20 minutes.

n Customization

Settings (e.g. the time elapsed before the lights turn off) can be changed. (Customizable features \rightarrow P. 666)